


KOHLER ENGINES

4-CYCLE • SHORT-STROKE • AIR-COOLED



MODEL K91RT

SPEC. NO. 31600-A

AS MANUFACTURED FOR

THE ESKA COMPANY

1.8 H.P. at 1800 R.P.M.

2.6 H.P. at 2400 R.P.M.

3.5 H.P. at 3200 R.P.M.

3.8 H.P. at 3600 R.P.M.

4.0 H.P. at 4000 R.P.M.

Kohler engines are manufactured under the close supervision of skilled technicians. The engines are precision units, machined and assembled to deliver many hours of reliable service. All components are produced under rigid inspection, tested under load conditions, and adjusted to meet exact specifications before shipment is made.

Kohler engines are solidly constructed with a heavy duty cast iron block, employing modern short stroke

design, and built-in mechanical governor.

This folder will assist you by offering the correct procedures for care of Kohler engines. For a K91 engine service manual with complete operation, maintenance, overhaul, and parts identification information, send \$1.50 to:

**Engine Service Department
Kohler Co., Kohler, Wisconsin**

OPERATING INSTRUCTIONS

1. Before Starting

- Remove oil filler cap and check oil level. Add clean oil to mark indicated on dipstick (SAE 5W-20). Oil should not be over full mark.
- Keep fuel tank filled with clean, fresh gasoline of regular grade to prevent condensation in cold weather. **DO NOT MIX OIL WITH GASOLINE.** Be sure fuel tank cap vent hole is open. Vent hole can freeze over while plowing.
- Remove both plugs of reduction gear unit and add oil, (same grade as used in crankcase) to oil level hole. Be sure that vent hole of oil fill plug is open. If oil bubbles out of vent hole of oil fill plug, there is too much oil.
- Break rotor blade free before starting.

2. To Start

- Open valve on sediment bowl.
- Close choke lever. Choking may be necessary due to variations in temperature, grade of fuel, etc. Little or no choking will be necessary when engine is warm. Experience will teach you the degree necessary under varying conditions. Open remote throttle about half way until engine starts, then set at desired speed.

Extreme Cold

Idle screw is set at factory for fast idle. Close throttle and set at full choke. When engine has started, open choke slowly, making adjustment

as engine warms up. Use Autolite AR8 spark plug or equivalent.

Below -25° F.

Apply heat to engine cylinder head, spark plug, and oil pan. Engine will start at -40° F. with heat application.

- Give starter pulley quick, steady pull. Do not jerk or pull retractable starter to end of cable—return handle slowly. **DO NOT ALLOW HANDLE TO SNAP BACK.**
- Slowly return choke to open position as engine warms up.

3. To Stop

Whenever possible, allow engine to idle, with no load, before stopping.


- Press red breaker point "STOP" button and *hold until engine is completely stopped.*
- See Instructions for Storing if engine is to be taken out of service for a considerable length of time.

4. Precautions

Stop engine before filling fuel tank. Avoid spilling gasoline on a hot engine. Always use fresh, clean gasoline.

- Avoid injuries. Always disconnect spark plug cable before making any adjustment to machine powered by engine.

Cont. on page 4



ESKA

MODEL K91RT - SPEC. NO. 31600-A

PARTS LIST

Item No.	Quantity	Part No.	Description	Item No.	Quantity	Part No.	Description	Item No.	Quantity	Part No.	Description
AIR INTAKE GROUP				DIPSTICK GROUP				IGNITION GROUP			
1	2	X-18-2	Washer, lock	46	1	220541	Head, cylinder	99	1	220132	Bushing, governor
2	2	X-51-43	Screw, R.H.M. 8-32x $\frac{3}{8}$	EXHAUST GROUP				100	1	220156	Bracket, speed control
50	1	220854	Cover, duct	48	1	A-220092	Dipstick—assembly	101	1	220380	Linkage, governor
51	1	220855	Body, duct	FLYWHEEL GROUP				97	1	220873	Disc, regulating
3	1	235308	Element	54	2	X-81-1	Nut, hex. $\frac{1}{4}$ —20	IGNITION GROUP			
4	1	220537	Gasket	55	2	220122	Gasket, muffler	104	1	X-5-1	Screw, H.C. $\frac{1}{4}$ —20x $\frac{5}{8}$
BAFFLES & SHROUD GROUP				56	1	A-220145	Muffler—assembly	104	1	X-20-1	Washer, lock $\frac{1}{4}$
5	2	X-132-1	Screw, H.C. $\frac{1}{4}$ —20x $\frac{3}{8}$	FUEL TANK & FITTINGS GROUP				104	1	X-22-18	Washer, lock 8 I.E.T.
6	4	X-132-5	Screw, H.C. $\frac{1}{4}$ —20x $\frac{5}{8}$	64	2	X-5-7	Screw, H.C. $\frac{1}{4}$ —20x1	104	1	X-25-48	Washer 8
8	1	220049	Baffle, head	65	2	X-101-8	Nut, stop $\frac{1}{4}$ —20	104	1	X-25-63	Washer $\frac{1}{4}$
9	1	220054	Baffle, cylinder	66	1	X-217-6	Nipple	105	2	X-67-22	Screw, self tapping 10
10	1	220220	Housing, blower	67	1	210101-A	Filter, fuel—assembly	102	1	X-67-37	Screw, self tapping 8—32x $\frac{5}{8}$
BREATHER & VENT GROUP				68	1	220097	Line, fuel	103	4	X-131-1	Screw, F.H.M. 10-24x $\frac{3}{8}$ (w/washer)
11	1	X-20-1	Washer, lock $\frac{1}{4}$	71	2	220154	Strap, tank	106	1	X-489-1	Rod, breaker
12	1	X-81-1	Nut, hex. $\frac{1}{4}$ —20	72	1	220158	Bracket, tank - L.H.	107	1	A-220136	Cover, breaker—assy.
13	1	210256	Filter	74	2	220166	Webbing	108	1	220174	Gasket
14	1	220357	Plate, breather	73	1	220514	Bracket, tank - R.H.	109	1	A-220409	Stator—assembly
15	1	220358	Cover, valve	1	1	220547	Sleeve	115	1	220435	Coil
16	1	220368	Stud, cover	1	1	220786	Nut	116	1	220434	Condenser
17	1	220369	Seal, breather	70	1	A-220852	Tank, fuel—assembly	110	1	A-220443	Cable, hi-tension
18	2	220370	Gasket, cover	1	1	220853	Cap, tank	111	1	A-220474	Breaker—assembly
19	1	220379	Reed, breather	69	1	231510	Elbow, compression	112	1	A-220512	Lead, breaker
CAMSHAFT & VALVES GROUP				GEAR REDUCTION GROUP				1	1	220856	Spring, stop control
20	1	220008	Valve, intake	76	2	X-5-4	Screw, H.C. $\frac{1}{4}$ —20x1 $\frac{1}{4}$	113	1	220857	Bracket, stop control
21	1	220009	Valve, exhaust	77	4	X-6-23	Screw, H.C. $\frac{5}{16}$ —24x $\frac{3}{4}$	113	1	240667	Plug, spark
22	2	220010	Spring, valve	78	4	X-20-1	Washer, lock $\frac{1}{4}$	114	1	275183	Clip, cable
23	2	220011	Retainer, spring	79	2	X-21-1	Washer, lock $\frac{5}{16}$	NAMEPLATE GROUP			
24	2	220013	Tappet, valve	80	1	X-75-2	Plug, pipe $\frac{1}{4}$	117	4	X-513-1	Screw, sheet metal —7x $\frac{3}{8}$
25	2	220052	Pin, valve lock	81	1	X-81-1	Nut, hex. $\frac{1}{4}$ —20	118	1	220630	Nameplate
26	1	220053	Pin, camshaft	82	1	X-230-11	Plug, expansion	1	1	220673	Decal, 4 H.P.
27	1	A-220140	Camshaft—assembly	83	1	X-271-15	Seal, gear cover	OIL PAN GROUP			
CARBURETOR GROUP				84	2	D-997	Washer, copper	120	1	X-75-2	Plug, pipe $\frac{1}{4}$
31	2	X-140-1	Screw, sltd. hd. $\frac{1}{4}$ —20x $\frac{3}{4}$	85	1	205013	Plug, pipe	122	4	X-154-1	Screw, H.C. $\frac{5}{16}$ —18x $\frac{7}{8}$
29	1	210223	Gasket, carburetor	86	1	220211	Housing, gear	113	1	220167	Pan, oil
32	1	E-220517	Carburetor—assembly	87	1	220212	Cover, gear	121	1	220775	Gasket, pan
1	1	231324	Decal, choke	88	1	220213	Gear, drive	PISTON & ROD GROUP			
30	1	231510	Elbow, compression	90	2	220216	Bushing, drive shaft	124	1	220467	Ring set—std.
28	1	220547	Sleeve	91	1	220218	Gasket, cover	1	1	B-220070	Rod, connecting—assy.
1	1	220786	Nut	89	1	220858	Shaft, gear	125	1	B220111	Connecting rod
CRANKCASE GROUP				GOVERNOR GROUP				126	1	220492	Lock, connecting rod
33	4	X-5-1	Screw, H.C. $\frac{1}{4}$ —20x $\frac{5}{8}$	92	1	X-5-7	Screw, H.C. $\frac{1}{4}$ —20x1	127	2	220491	Screw, connecting rod
34	4	X-25-55	Washer, copper $\frac{1}{4}$	93	2	X-25-63	Washer $\frac{1}{4}$	128	1	A-220103	Piston—assy., std.
35	1	X-271-15	Seal, front oil	94	1	X-67-5	Screw, drive	129	2	220004	Retainer, pin
36	1	X-271-16	Seal, rear oil	95	1	X-81-1	Nut, hex. $\frac{1}{4}$ —20	130	1	220003	Pin, piston
37	1	X-301-6	Button, plug	96	1	X-269-13	Ring, snap	RETRACTABLE STARTER GROUP			
38	2	200110	Bearing, ball	97	1	220119	Spring, governor	131	4	X-19-1	Washer, lock 10
39	1	220071	Gasket, bearing plate	98	1	220126	Lever, governor	4	4	X-25-7	Washer 10
40	1	220385	Plate, bearing	GOVERNOR GROUP				132	4	X-50-2	Screw, R.H.M. 10-32x $\frac{3}{8}$
41	1	A-220459	Block, cylinder—assy.	92	1	X-5-7	Screw, H.C. $\frac{1}{4}$ —20x1	133	1	C-220589	Starter, recoil—assy.
CRANKSHAFT GROUP				93	2	X-25-63	Washer $\frac{1}{4}$	134	1	A-220594	Cup, drive w/screen
42	1	220433	Crankshaft	94	1	X-67-5	Screw, drive	220151 Gasket set			
CYLINDER HEAD GROUP				95	1	X-81-1	Nut, hex. $\frac{1}{4}$ —20				
43	1	220124	Gasket, head	96	1	X-269-13	Ring, snap				
44	6	220257	Screw, H.C. $\frac{5}{16}$ x18x1— $\frac{1}{4}$	97	1	220119	Spring, governor				
45	6	220534	Washer $\frac{5}{16}$	98	1	220126	Lever, governor				
				98	1	220131	Shaft, governor				

Pour engine oil into gear housing at filler hole until oil runs from oil level hole at lower end.

Indented part numbers and descriptions are components of preceding assembly.

Order parts from your nearest Kohler dealer giving part number and description of part and model number, specification number and serial number of engine.

BrentChalmers.com

GEAR REDUCTION

The reduction unit is a gear type running in oil. The drive gear is machined on the crankshaft and the driven gear is keyed and pressed onto the power-take-off shaft. The shaft is supported by two bronze bearings located in the gear housing and in the gear cover.

1. Before Operating

- a. Remove oil fill plug and oil level plug and fill gear unit to oil level hole. Use same grade of oil recommended for engine.
- b. The reduction gear is vented through the oil fill plug. This vent should be checked daily to see that it is open.
- c. Change reduction gear oil every 100 operating hours.


2. To Service

- a. Remove four cap screws from gear housing, slide off cover and remove power-take-off with driven gear.

- b. Remove four cap screws that hold gear housing to engine block. Use socket wrench.
- c. Wash all parts and inspect shaft, bushing, and gears for wear. Replace all worn parts.
- d. Remove old oil seals and install new seals (flat side out) in gear housing and reduction gear cover.

3. Assembly

- a. Wrap tape around crankshaft gear to protect oil seal, slide gear reduction housing over shaft and attach to block. Two lock washers are used on outside and copper washers inside.
- b. Place thrust washers on shaft, one on each side of reduction gear.
- c. Tape should be wrapped around shaft to prevent keyway from damaging oil seal while cover is installed on power-take-off shaft.
- d. Install gaskets on cover and place assembly in position on gear housing.



CONTACT YOUR NEAREST KOHLER DEALER FOR REPAIR PARTS

KOHLER CO. Established 1873 KOHLER, WIS.

K O H L E R

O F K O H L E R
BrentChalmers.com

- b. Crankcase and air cleaner must be properly serviced at all times. Dirt drawn through improperly serviced air cleaner can ruin an engine in a few operating hours.
- c. Allow engine to warm up before applying work load.

- d. Keep cylinder block, flywheel, cylinder head cooling fins, and rotating air screen free of ice and snow.
- e. Do not operate at speeds greater than governor setting or run continuously under maximum load.

MAINTENANCE

1. Each Day

- a. Check fuel supply and oil level in crankcase. Add oil only as needed to keep level between marks on oil gauge.
- b. Clean oil, dirt, and snow from external surface of power unit.
- c. Check air intake and cooling fins for obstructions and ice.

2. Every 25 Operating Hours

- a. Change oil in crankcase.
- b. Check gasket joints between air cleaner, carburetor, and air intake manifold.

3. Every 100 Operating Hours

Perform 25 hour service and in addition:

- a. File electrode areas and regap spark plug to .025. Use Autolite AR-8 plugs, or equivalent, for cold weather operation.
- b. Remove, clean, and replace sediment bowl.

- c. Check breaker points and regap to .020.

- d. Oil recoil starter through hole indicated on starter housing. Use lube equivalent to #5 grade oil.

4. Instructions for Storing

If engine is to be out of service for a considerable length of time, the following procedure is recommended:

- a. Drain fuel tank.
- b. Drain carburetor by pressing bowl drain button on bottom of carburetor bowl.
- c. Remove, clean, and replace sediment bowl.
- d. Clean exterior surfaces of engine.
- e. Spread a light film of oil over any exposed surfaces of engine subject to corrosion.
- f. Pour tablespoon of oil into spark plug hole and crank engine slowly by hand. Replace plug.
- g. Do not expose to elements—store in dry place.

TROUBLE SHOOTING

Following is a list of troubles which may occur through average use and normal wear:

1. Hard Starting

- a. Faulty Ignition
 - (1) Loose or grounded high tension on breaker point leads.
 - (2) Improper breaker point gap.
 - (3) Defective breaker points.
 - (4) Faulty spark plugs.
 - (5) Faulty condenser or coil.
 - (6) Incorrect spark timing.
 - (7) Check ignition system for moisture.
- b. Faulty Carburetion
 - (1) Gasoline not getting to carburetor.
 - (a) Ice, dirt or gum deposits in fuel line.
 - (2) Dirt in carburetor.
 - (3) Carburetor improperly adjusted.
- c. Compression Loss
 - (1) Valves leaking or sticking.
 - (2) Rings worn.
 - (3) Head gasket leaking.

2. Overheating

- a. Insufficient cooling air available.
- b. Dirty or clogged intake screen, shroud or cooling fins.
- c. Improper fuel.
- d. Fuel mixture too lean.
- e. Improper ignition timing.

3. Backfiring

- a. Fuel mixture too lean.
- b. Sticky intake valve.
- c. Improper ignition timing.
- d. Point gap open too far.

4. Occasional Missing at High Speed

- a. Spark plug gap too wide.
- b. Improper carburetor adjustment or lack of fuel.
- c. Wrong type spark plug.
- d. Improper ignition timing.

5. Missing Under Slow, Hard Pull

- a. Spark plug gap too wide.
- b. Pitted breaker points.

- c. Partially fouled spark plug.
- d. Defective ignition timing.

6. Knocking

- a. Fuel octane rating too low. Use a good grade of regular gasoline.
- b. Improper ignition timing.
- c. Overheated engine.
- d. Loose connecting rod.
- e. Excessive carbon in combustion chamber.
- f. Lack of lubrication.

7. Operating Erratically

- a. Clogged fuel line.
- b. Water in fuel.
- c. Faulty choke control.

- d. Improper fuel mixture.
- e. Loose ignition system connection.
- f. Air leaks in manifold or carburetor connections.

8. Engine Will Not Idle

- a. Improper carburetor idling adjustment.
- b. Carburetor jets clogged.
- c. Spark plug gap too small. .025.
- d. Leaking carburetor or manifold gaskets.
- e. Sticking or leaking valves.
- f. Weak coil or condenser.

9. Engine Stops While In Operation

- a. Check fuel tank cap vent hole.
- b. Air cleaner can be clogged with fine snow.

CARBURETOR ADJUSTMENTS

The carburetor is adjusted at the factory and under normal operating conditions will not require readjustment. If adjustment is necessary because of fuel values and/or air conditions, the following procedure is recommended:

- a. Turn high speed adjustment screw (center vertical screw on top of carburetor) counter-clockwise two full turns from closed position and start engine.
- b. After engine has reached normal operating temperature, accelerate and check response. Operate engine under full load and adjust high speed needle for a slightly richer mixture for improved cooling and greater power.
- c. If engine misses and backfires, high speed mixture is too lean. To correct—high speed adjustment screw should be turned counter-clockwise, $\frac{1}{4}$ turn at a time, until condition is corrected.

- d. If engine shows sooty exhaust and is sluggish, mixture is too rich. To correct—high speed adjustment screw should be turned clockwise until engine runs smoothly.
- e. To make final check of high speed adjustment, operate under full load and make corrections to achieve smooth operation.
- f. Idle speed is controlled by stop screw on carburetor throttle shaft and should be set at a speed not less than 1000 RPM.
- g. Adjustments to idle mixture screw (angled screw on side of carburetor) and idle stop screw should be made at the same time as each affects the other. Adjust until engine idles smoothly.

WARNING: *Do not use force on high speed needle or idle screw—they will be damaged.*

RECOIL STARTER

The starter has a die cast aluminum housing. A friction shoe assembly, under spring tension, is used to engage in the drive cup when starter handle is pulled. The drive cup is held in place on engine by the flywheel nut. A pin on the cup is engaged in the crankshaft keyway to prevent slippage of the drive cup.

1. To Align Starter

- a. Place in desired position on blower housing with centering pin engaged in center hole of crankshaft. If centering pin is too short to reach crankshaft, pull pin out to correct length with a pair of pliers.

2. Operating Tips

- a. Be sure starter screen is kept clean when engine

is operating. Severe damage may result from overheating.

- b. After starting engine, return cable slowly. Releasing handle when cable is extended will shorten life of starter.
- c. Use a steady pull to start engine. Jerking cable to the end will result in wear.
- d. Pull handle so that cable will remain centered in guides.

If for any reason recoil starter should not operate, starter assembly can be removed and engine cranked with a rope. The starter cup will serve as a rope pulley.